



since 1920 valves with reliability



ALLIGATOR TPMS Service Kits

For tyre service - with each tyre change


ALLIGATOR TPMS Service Kits contain all components that are necessary for the correct and thorough service on tyres and rims with TPMS. The "Kits" are assigned according to the features "Manufacturer, Model & Year".



Which components have to be replaced?

As a matter of principle, the relevant components of a TPMS valve must be replaced.

- valve sealing cap
- valve core
- rubber seal
- hex nut



are subject to influences of ageing and corrosion.

Additionally the rubber seals and valves are particularly stressed by the TPM sensors installed in the wheels, due to the weight of the sensor. For this reason it is highly recommended to replace these components during the tyre service!



The ALLIGATOR TPMS service kits box

includes all components required for the correct and thorough service of tyres and rims in OE quality.

TPMS Service Kit Box

Part no. 591394

Includes:

- 13 popular service kits at 5 pieces
- 100 valve cores
- 100 sealing caps

